

Make	Model	Engine	Year	DECOOL #	Purpose
HYUNDAI	ATOS (MX)	1.0 i	1998-2002	9177	PASSENGER
HYUNDAI	Accent	4-Cyl. 1.5 L	1997-1996	9392/9392A/9392B	PASSENGER
HYUNDAI	Accent	4-Cyl. 1.6 L	2011-2001	9392/9392A/9392B	PASSENGER
HYUNDAI	Accent	4-Cyl. 1.5 L	2002-1998	9502	PASSENGER
HYUNDAI	Accent	4-Cyl. 1.5 L	1997-1996	9502	PASSENGER
HYUNDAI	Accent	4-Cyl. 1.5 L	1995	9502	PASSENGER
HYUNDAI	Accent	4-Cyl. 1.5 L	2003	9502	PASSENGER
HYUNDAI (BEIJING)	ACCENT	4-1.6	2006-	9522	PASSENGER
HYUNDAI	ACCENT II (LC)	1.5	02/04-05/11	9648	PASSENGER
HYUNDAI	ACCENT II Saloon (LC)	1.5	02/01-05/11	9648	PASSENGER
HYUNDAI	ATOS (MX) 1.0 i GLS	1.0 i	2001-2003	9177	PASSENGER
HYUNDAI	COUPE (GK)	4-2.0 GLS	2003-2009	9522	PASSENGER
HYUNDAI	COUPE (GK) 2.0	4-2.0	2002-2009	9522	PASSENGER
HYUNDAI	COUPE (GK) 2.0 GLS	4-2.0	2003-2009	9522	PASSENGER
HYUNDAI	COUPE (RD)	4-1.6	1998-2002	9522	PASSENGER
HYUNDAI	COUPE (RD)	4-2.0	1996-2002	9522	PASSENGER
HYUNDAI	COUPE (RD) 1.6 16V	4-1.6	1998-2002	9322	PASSENGER
HYUNDAI	COUPE (RD) 1.6 i 16V	4-1.6	1996-2002	9322	PASSENGER
HYUNDAI	COUPE (RD) 2.0 16V	4-2.0	1996-2002	9322	PASSENGER
HYUNDAI	COUPE (RD) 2.0 16V	4-2.0	2001-2002	9522	PASSENGER
HYUNDAI	ELANTRA	L4-1.8L	98-96	9522	PASSENGER
HYUNDAI	ELANTRA	L4-2.0L	12-99	9522	PASSENGER
HYUNDAI	ELANTRA (XD)	2.0L	01/04-06/07	9648	PASSENGER
HYUNDAI	ELANTRA (XD) 1.8	4-1.8	2000-2006	9522	PASSENGER
HYUNDAI	ELANTRA (XD) 2.0	4-2.0	2000-2006	9522	PASSENGER
HYUNDAI	ELANTRA (XD) 2.0	4-2.0	2000-2006	9522	PASSENGER
HYUNDAI	ELANTRA (XD) 2.0	4-2.0	2003-2006	9522	PASSENGER
HYUNDAI	ELANTRA II (J-2) 1.6 16V	4-1.6	1995-2000	9322	PASSENGER
HYUNDAI	ELANTRA II (J-2) 1.6 16V	4-1.6	1995-2000	9522	PASSENGER
HYUNDAI	ELANTRA II (J-2) 1.6 i	4-1.6	1995-2000	9322	PASSENGER
HYUNDAI	ELANTRA II (J-2) 1.6 i	4-1.6	1995-2000	9522	PASSENGER
HYUNDAI	ELANTRA II (J-2) 1.8 16V	4-2.0	1995-2000	9322	PASSENGER
HYUNDAI	ELANTRA II (J-2) 2.0 16V	4-2.0	1996-2000	9322	PASSENGER
HYUNDAI	ELANTRA II (J-2) 2.0 16V	4-2.0	1996-2000	9522	PASSENGER
HYUNDAI	ELANTRA II Wagon (J-2) 1.6 16V	4-1.6	1996-2000	9522	PASSENGER
HYUNDAI	ELANTRA II Wagon (J-2) 1.6 i	4-1.6	1996-2000	9522	PASSENGER
HYUNDAI	ELANTRA II Wagon (J-2) 2.0 16V	4-2.0	1996-2000	9522	PASSENGER
HYUNDAI (BEIJING)	ELANTRA Saloon	4-1.6	2003-	9522	PASSENGER
HYUNDAI (BEIJING)	ELANTRA Saloon	4-1.8	2003-	9522	PASSENGER
HYUNDAI	ELANTRA Saloon (MD, UD)	4-1.8	2010-	9589	PASSENGER
HYUNDAI	ELANTRA Saloon (XD)	2.0L	01/04-06/07	9648	PASSENGER
HYUNDAI	ELANTRA Saloon (XD) 1.8	4-1.8	2000-2006	9522	PASSENGER
HYUNDAI	ELANTRA Saloon (XD) 2.0	4-2.0	2000-2006	9522	PASSENGER
HYUNDAI	ELANTRA Saloon (XD) 2.0	4-2.0	2000-2006	9522	PASSENGER
HYUNDAI	ELANTRA Saloon (XD) 2.0	4-2.0	2003-2006	9522	PASSENGER

Make	Model	Engine	Year	DECOOL #	Purpose
HYUNDAI	Excel	4-Cyl. 1.5 L	1994-1986	9502	PASSENGER
HYUNDAI	GETZ (TB)	1.5	03/03-05/09	9648	PASSENGER
HYUNDAI	GETZ (TB)	1.5	04/07-05/08	9648	PASSENGER
HYUNDAI	GETZ (TB)	1.1	2005-2009	9177	PASSENGER
HYUNDAI	H-1 Box 2.4	4-2.4	2000-2004	9528/9528A	PASSENGER
HYUNDAI	H-1 Bus (KMF) 2.4	4-2.4	1997-	9528/9528A	PASSENGER
HYUNDAI	H-1 Bus (KMF) 2.4 4WD	4-2.4	1997-	9528/9528A	PASSENGER
HYUNDAI	i30 (FD) 2.0	4-2.0	2007-2011	9322	PASSENGER
HYUNDAI	i30 CW (FD) 2.0	4-2.0	2008-2012	9322	PASSENGER
HYUNDAI	i40 (VF)	4-2.0	2012-	9589	PASSENGER
HYUNDAI	i40 CW (VF)	4-2.0	2011-	9589	PASSENGER
HYUNDAI	LANTRA II Wagon (J-2) 1.6 16V	4-1.6	1996-2000	9322	PASSENGER
HYUNDAI	LANTRA II Wagon (J-2) 1.8 16V	4-2.0	1996-2000	9322	PASSENGER
HYUNDAI	LANTRA II Wagon (J-2) 2.0 16V	4-2.0	1996-2000	9322	PASSENGER
HYUNDAI	MATRIX (FC)	1.5	01/10-10/08	9648	PASSENGER
HYUNDAI	MATRIX (FC) 1.8	4-1.8	2001-2010	9522	PASSENGER
HYUNDAI	SANTA FE	L4-2.4L	2010	6215	PASSENGER
HYUNDAI	Santa Fe	V-6 2.7 L	2006-2001	9383/9383A	PASSENGER
HYUNDAI	SANTA FE	V6-3.5L	2006-2003	9393	PASSENGER
HYUNDAI	Santa Fe	V-6 2.7 L	2009-2007	9409/9409A	PASSENGER
HYUNDAI	Santa Fe	4-Cyl. 2.4 L	2004-2001	9518	PASSENGER
HYUNDAI	Santa Fe	4-Cyl. 2.4 L	2006-2005	9518	PASSENGER
HYUNDAI	SANTA Fé I (SM)	2.0L	03/08-06/03	9648	PASSENGER
HYUNDAI	SANTA Fé I (SM)	2.0L	01/04-06/03	9648	PASSENGER
HYUNDAI	SANTA Fé I (SM)	2.0L	01/08-06/03	9648	PASSENGER
HYUNDAI	SANTA Fé I (SM)	2.0L	03/11-06/02	9648	PASSENGER
HYUNDAI	Scoupe	4-Cyl. 1.5 L	1995-1991	9502	PASSENGER
HYUNDAI	SONATA	L4-2.4L	2010-2006	6215	PASSENGER
HYUNDAI	Sonata	V-6 3.0 L	1998-1990	9323	PASSENGER
HYUNDAI	Sonata	V-6 2.5 L	2001-1999	9383/9383A	PASSENGER
HYUNDAI	Sonata	V-6 2.7 L	2005-2002	9383/9383A	PASSENGER
HYUNDAI	Sonata	4-Cyl. 2.4 L	2010-2006	9406	PASSENGER
HYUNDAI	Sonata	4-Cyl. 2.4 L	2005-1999	9518	PASSENGER
HYUNDAI	Sonata	2.0		9589	PASSENGER
HYUNDAI (BEIJING)	SONATA (EF)	4-2.0	2002-2007	9522	PASSENGER
HYUNDAI	Tiburon	V-6 2.7 L	2008-2003	9383/9383A	PASSENGER
HYUNDAI	TIBURON	L4-1.8L	1997	9522	PASSENGER
HYUNDAI	TIBURON	L4-2.0L	01-97	9522	PASSENGER
HYUNDAI	TIBURON	L4-2.0L	08-03.	9522	PASSENGER
HYUNDAI	TRAJET (FO)	2.0L	01/04-08/07	9648	PASSENGER
HYUNDAI	TRAJET (FO)	2.0L	05/08-08/07	9648	PASSENGER
HYUNDAI	TRAJET (FO) 2.0	4-2.0	2004-2008	9322	PASSENGER
HYUNDAI	TUCSON	L4-2.0L	2011	6215	PASSENGER
HYUNDAI	TUCSON	L4-2.4L	2012-2010	6215	PASSENGER
HYUNDAI	Tucson	V-6 2.7 L	2009-2005	9383/9383A	PASSENGER

Make	Model	Engine	Year	DECOOL #	Purpose
HYUNDAI	TUCSON	L4-2.0L	09-05.	9522	PASSENGER
HYUNDAI	TUCSON (JM)	2.0L	04/08-10/03	9648	PASSENGER
HYUNDAI	TUCSON (JM) 2.0	4-2.0	2004-2010	9322	PASSENGER
HYUNDAI	TUCSON (JM) 2.0 All-wheel Drive	4-2.0	2004-2010	9322	PASSENGER
HYUNDAI (BEIJING)	TUCSON Closed Off-Road Vehicle	4-2.0	2005-	9522	PASSENGER
HYUNDAI (BEIJING)	TUCSON Closed Off-Road Vehicle 2.0	4-2.0	2005-	9522	PASSENGER
HYUNDAI (BEIJING)	TUCSON Closed Off-Road Vehicle 2.0 All-wheel Drive	4-2.0	2005-	9522	PASSENGER
HYUNDAI	XG300	V6-3.0L	2001	9393	PASSENGER
HYUNDAI	XG350	V6-3.5L	2005-2002	9393	PASSENGER