

Make	Model	Engine	Year	DECOOL #	Purpose
ISUZU	HOMBRE	V6-4.3L	00-97	3101	PASSENGER
ISUZU	NPR	V8-5.7L	02-96	3101	PASSENGER
ISUZU	NPR TRUCK; (5.7L) 350		2002-1996	3101	PASSENGER
ISUZU	NPR-HD	V8-5.7L	02-99	3101	PASSENGER
ISUZU	Ascender	V-8 5.3 L	2005-2003	3506\3506A	PASSENGER
ISUZU	Ascender	6-Cyl. 4.2 L	2008-2003	9326	PASSENGER
ISUZU	I-280	4-Cyl. 2.8 L	2006	9326	PASSENGER
ISUZU	I-290	4-Cyl. 2.9 L	2008-2007	9326	PASSENGER
ISUZU	I-350	5-Cyl. 3.5 L	2006	9326	PASSENGER
ISUZU	I-370	5-Cyl. 3.7 L	2008-2007	9326	PASSENGER
ISUZU	Hombre	4-Cyl. 2.2 L	2000-1996	9331	PASSENGER
ISUZU	Oasis	4-Cyl. 2.2 L	1997-1996	9352	PASSENGER
ISUZU	Oasis	4-Cyl. 2.3 L	1999-1998 .	9352	PASSENGER
ISUZU	Amigo	4-Cyl. 2.6 L	1994-1989	9365/9365A	PASSENGER
ISUZU	Pickup	4-Cyl. 2.6 L	1995-1988	9365/9365A	PASSENGER
ISUZU	Rodeo	4-Cyl. 2.6 L	1997-1991	9365/9365A	PASSENGER
ISUZU	Trooper	4-Cyl. 2.6 L	1991-1990	9365/9365A	PASSENGER
ISUZU	Trooper II	4-Cyl. 2.6 L	1989-1988	9365/9365A	PASSENGER
ISUZU	Amigo	4-Cyl. 2.3 L	1993-1989 .	9506	PASSENGER
ISUZU	Impulse	4-Cyl. 2.3 L	1989-1988	9506	PASSENGER
ISUZU	Pickup	4-Cyl. 2.3 L	1995-1986	9506	PASSENGER
ISUZU	Trooper II	4-Cyl. 2.3 L	1987-1986	9506	PASSENGER
ISUZU	AMIGO	V6-3.2L	2000-1998	9638	PASSENGER
ISUZU	AXIOM	V6-3.5L	2004-2002	9638	PASSENGER
ISUZU	RODEO	V6-3.2L	2004-1998	9638	PASSENGER
ISUZU	RODEO	V6-3.5L	2004	9638	PASSENGER
ISUZU	RODEO SPORT	V6-3.2L	2003-2001	9638	PASSENGER
ISUZU	TROOPER	V6-3.5L	2002-1998	9638	PASSENGER
ISUZU	VEHICROSS	V6-3.5L	2001-1999	9638	PASSENGER
ISUZU	Amigo	4-Cyl. 2.2 L	2000-1998	9384/9384A/9384B	PASSENGER
ISUZU	Rodeo	4-Cyl. 2.2 L	2003-1998	9384/9384A/9384B	PASSENGER
ISUZU	RODEO SPORT	L4-2.2L	2003-2001	9384/9384A/9384B	PASSENGER