

Make	Model	Engine	Year	DECOOL #	Purpose
LEXUS	CT (ZWA1_) 200h	1.8L	10/12 - /	1209	PASSENGER
LEXUS	ES300	V-6 3.0 L	2003-1994	9318	PASSENGER
LEXUS	ES330	V-6 3.3 L	2006-2004	9318	PASSENGER
LEXUS	ES350	V-6 3.5 L	2013	9448	PASSENGER
LEXUS	ES350	V6 3.5L	2007-2011	9576/9576U	PASSENGER
LEXUS	GS	2.0L	2015-	9674	PASSENGER
LEXUS	GS (UZS161, JZS160)	3.0L	97/08-00/10	9645	PASSENGER
LEXUS	GS (UZS161, JZS160)	3.0L	00/10-05/03	9645	PASSENGER
LEXUS	GS300	V-6 3.0 L	2006	9448	PASSENGER
LEXUS	GS350	V-6 3.5 L	2013	9448	PASSENGER
LEXUS	GS350	V-6 3.5 L	2011-2007	9448	PASSENGER
LEXUS	GS450h	V-6 3.5 L Electric Assist	2013	9448	PASSENGER
LEXUS	GS450h	V-6 3.5 L Electric Assist	2011-2007	9448	PASSENGER
LEXUS	GS460	V8-4.6L	2011-2008	9425	PASSENGER
LEXUS	HS250h	4-Cyl. 2.4 L Electric Assist	2012-2010	9354	PASSENGER
LEXUS	IS F	V8-5.0L	2012-2008	9425	PASSENGER
LEXUS	IS I (JCE1_, GXE1_)	3.0L	01/09-05/07	9645	PASSENGER
LEXUS	IS III	2.0L	2015-	9674	PASSENGER
LEXUS	IS SportCross	3.0L	01/10-05/10	9645	PASSENGER
LEXUS	IS250	V-6 2.5 L	2014-2006	9448	PASSENGER
LEXUS	IS350	V-6 3.5 L	2014-2006	9448	PASSENGER
LEXUS	LS460	V8-4.6L	2012-2007	9425	PASSENGER
LEXUS	LS600H	V8-5.0L	2012-2008	9425	PASSENGER
LEXUS	LX450	L6-4.5L	97-96	9464	PASSENGER
LEXUS	LX570	V8-5.7L	2011-2008	9418	PASSENGER
LEXUS	LX570	V8-5.7L	2013	9418	PASSENGER
LEXUS	NX	2.0L	2014-	9674	PASSENGER
LEXUS	NX	2.0L	2014-	9681	PASSENGER
LEXUS	RC	2.0L	2015-	9674	PASSENGER
LEXUS	RX	2.0L	2015-2017	9674	PASSENGER
LEXUS	RX300	V-6 3.0 L	2003-1999	9318	PASSENGER
LEXUS	RX330	V-6 3.3 L	2006-2004	9318	PASSENGER
LEXUS	RX350	V6 3.5L	2007-2011	9576/9576U	PASSENGER
LEXUS	RX400h	V-6 3.3 L	2009-2006	9318	PASSENGER
LEXUS	RX450H	V6 3.5L	2010-2011	9576/9576U	PASSENGER