

Make	Model	Engine	Year	DECOOL #	Purpose
MAZDA	3	4-Cyl. 2.0 L	2005-2004	9336/9336A	PASSENGER
MAZDA	3	4-Cyl. 2.3 L	2013-2010	9336/9336A	PASSENGER
MAZDA	3	4-Cyl. 2.3 L	2008	9336/9336A	PASSENGER
MAZDA	3	4-Cyl. 2.3 L	2005-2004	9336/9336A	PASSENGER
MAZDA	5	4-Cyl. 2.3 L	2007-2006	9336/9336A	PASSENGER
MAZDA	6	4-Cyl. 2.3 L	2005-2003	9336/9336A	PASSENGER
MAZDA	6	4-Cyl. 2.5 L	2010-2009	9336/9336A	PASSENGER
MAZDA	323	4-Cyl. 1.6 L	1989-1988	9357	PASSENGER
MAZDA	626	4-Cyl. 2.0 L	2002-1993	9337/9337A	PASSENGER
MAZDA	626	4-Cyl. 2.2 L	1992-1988	9356	PASSENGER
MAZDA	626	V-6 2.5 L	1994-1993	9371	PASSENGER
MAZDA	626	V-6 2.5 L	2002-1995	9373	PASSENGER
MAZDA	626	V-6 2.5 L	1994-1993	9373	PASSENGER
MAZDA	626	4-Cyl. 2.0 L	1987	9499	PASSENGER
MAZDA	626	4-Cyl. 2.0 L	1986-1984	9499	PASSENGER
MAZDA	626	4-Cyl. 2.0 L	1986-1984	9560	PASSENGER
MAZDA	626	4-Cyl. 2.0 L	1983	9560	PASSENGER
MAZDA	2 (DE) 1.3	4-1.4	2007-2015	9570/9570P	PASSENGER
MAZDA	2 (DE) 1.3	4-1.4	2007-2015	9570/9570P	PASSENGER
MAZDA	2 (DE) 1.3 MZR	4-1.4	2010-2015	9570/9570P	PASSENGER
MAZDA	2 (DE) 1.5	4-1.5	2007-2015	9570/9570P	PASSENGER
MAZDA	2 (DE) 1.5 MZR	4-1.5	2011-2015	9570/9570P	PASSENGER
MAZDA	3 (BK) 1.4	4-1.4	2003-2009	9570/9570P	PASSENGER
MAZDA	3 (BK) 1.6	4-1.6	2003-2009	9570/9570P	PASSENGER
MAZDA	3 (BL) 1.6 MZR	4-1.6	2009-	9570/9570P	PASSENGER
MAZDA	3 (BM) 1.5	4-1.5	2013-	6219	PASSENGER
MAZDA	3 (BM) 1.5	4-1.5	2013-	6219	PASSENGER
MAZDA	3 (BM) 1.6	4-1.6	2013-	9570/9570P	PASSENGER
MAZDA	3 (BM) 2.0	4-2.0	2013-	6219	PASSENGER
MAZDA	3 (BM) 2.0	4-2.0	2013-	6219	PASSENGER
MAZDA	3 Saloon (BK) 1.6	4-1.6	2004-	9570/9570P	PASSENGER
MAZDA	3 Saloon (BL) 1.6 MZR	4-1.6	2009-	9570/9570P	PASSENGER
MAZDA	3 Saloon (BM) 1.5	4-1.5	2014-	6219	PASSENGER
MAZDA	3 Saloon (BM) 1.5	4-1.5	2013-	6219	PASSENGER
MAZDA	3 Saloon (BM) 1.6	4-1.6	2013-	9570/9570P	PASSENGER
MAZDA	3 Saloon (BM) 2.0	4-2.0	2013-	6219	PASSENGER
MAZDA	6 Estate (GJ, GH) 2.0	4-2.0	2013-	6219	PASSENGER
MAZDA	6 Estate (GJ, GH) 2.0	4-2.0	2013-	6219	PASSENGER
MAZDA	6 Estate (GJ, GH) 2.5	4-2.5	2012-	6219	PASSENGER
MAZDA	6 Saloon (GH) 3.7	3.7L	2008-2013	9176/9176A	PASSENGER
MAZDA	6 Saloon (GJ, GH) 2.0	4-2.0	2013-	6219	PASSENGER
MAZDA	6 Saloon (GJ, GH) 2.0	4-2.0	2013-	6219	PASSENGER
MAZDA	6 Saloon (GJ, GH) 2.5	4-2.5	2013-	6219	PASSENGER
MAZDA	B2000 Pickup	4-Cyl. 2.0 L	1987	9499	PASSENGER
MAZDA	B2000 Pickup	4-Cyl. 2.0 L	1986	9499	PASSENGER

Make	Model	Engine	Year	DECOOL #	Purpose
MAZDA	B2000 Pickup	4-Cyl. 2.0 L	1986	9560	PASSENGER
MAZDA	B2200 Pickup	4-Cyl. 2.2 L	1993-1987	9356	PASSENGER
MAZDA	B2300 Pickup	4-Cyl. 2.3 L	2001	9358	PASSENGER
MAZDA	B2300 Pickup	4-Cyl. 2.3 L	1997-1995	9358	PASSENGER
MAZDA	B2300 Pickup	4-Cyl. 2.3 L	2009-2002	9336/9336A	PASSENGER
MAZDA	B2300 Pickup	4-Cyl. 2.3 L	2010	9336/9336A	PASSENGER
MAZDA	B2500 Pickup	4-Cyl. 2.5 L	2001-1998	9358	PASSENGER
MAZDA	B2600	L4-2.6L	93-89	9642	PASSENGER
MAZDA	B3000	V6-3.0L	1999-2003	9561	PASSENGER
MAZDA	B3000	V6-3.0L	1998	9561	PASSENGER
MAZDA	B3000	V6-3.0L	2001-2007	9561	PASSENGER
MAZDA	B3000	V6-3.0L	1995-1997	9561	PASSENGER
MAZDA	B4000 Pickup	V-6 4.0 L	2000-1994	3503/3503A	PASSENGER
MAZDA	B4000 Pickup	V-6 4.0 L	2009-2001	3504	PASSENGER
MAZDA	B4000 Pickup	V-6 4.0 L	2010	3504	PASSENGER
MAZDA	CX-5	2.0L	2012-2017	9690	PASSENGER
MAZDA	CX-5 (KE, GH) 2.0	4-2.0	2011-	6219	PASSENGER
MAZDA	CX-5 (KE, GH) 2.0	4-2.0	2012-	6219	PASSENGER
MAZDA	CX-5 (KE, GH) 2.0 AWD	4-2.0	2011-	6219	PASSENGER
MAZDA	CX-5 (KE, GH) 2.0 AWD	4-2.0	2012-	6219	PASSENGER
MAZDA	CX-5 (KE, GH) 2.0 AWD	4-2.0	2012-	6219	PASSENGER
MAZDA	CX-5 (KE, GH) 2.5 AWD	4-2.5	2015-	6219	PASSENGER
MAZDA	CX-7	4-Cyl. 2.3 L	2012-2011	9336/9336A	PASSENGER
MAZDA	CX-7	4-Cyl. 2.3 L	2009-2007	9336/9336A	PASSENGER
MAZDA	CX-9 (TB) 3.7	3.7L	2007-	9176/9176A	PASSENGER
MAZDA	CX-9 (TB) 3.7 AWD (TB10A)	3.7L	2007-	9176/9176A	PASSENGER
MAZDA	Millenia	V-6 2.5 L	2002-1995	9373	PASSENGER
MAZDA	MILLENNIA	V6-2.3L	02-95	9640	PASSENGER
MAZDA	MPV	V-6 2.5 L	2001-2000	6202/6202A	PASSENGER
MAZDA	MPV	V-6 3.0 L	2002	6202/6202A	PASSENGER
MAZDA	MPV	V6-3.0L	2006-2003	6206	PASSENGER
MAZDA	MPV	V6-2.5L	2001-2000	9311	PASSENGER
MAZDA	MPV	V6-3.0L	2003-2002	9311	PASSENGER
MAZDA	MPV	V6-3.0L	2006-2003	9630	PASSENGER
MAZDA	MPV	L4-2.6L	94-89	9642	PASSENGER
MAZDA	MX-3	4-Cyl. 1.6 L	1995-1994	9366	PASSENGER
MAZDA	MX-3	4-Cyl. 1.6 L	1996	9366	PASSENGER
MAZDA	MX-3	V-6 1.8 L	1993-1992	9371	PASSENGER
MAZDA	MX-3	V-6 1.8 L	1994	9373	PASSENGER
MAZDA	MX-3	V-6 1.8 L	1993-1992	9373	PASSENGER
MAZDA	MX-5 Miata	4-Cyl. 1.6 L	1993-1990	9357	PASSENGER
MAZDA	MX-5 Miata	4-Cyl. 1.8 L	2005-1999	9366	PASSENGER
MAZDA	MX-5 Miata	4-Cyl. 1.8 L	1997-1994	9366	PASSENGER
MAZDA	MX-6	4-Cyl. 2.0 L	1997-1993	9337/9337A	PASSENGER
MAZDA	MX-6	4-Cyl. 2.2 L	1992-1988	9356	PASSENGER

Make	Model	Engine	Year	DECOOL #	Purpose
MAZDA	MX-6	V-6 2.5 L	1994-1993	9371	PASSENGER
MAZDA	MX-6	V-6 2.5 L	1997-1995	9373	PASSENGER
MAZDA	MX-6	V-6 2.5 L	1994-1993	9373	PASSENGER
MAZDA	Navajo	V-6 4.0 L	1994-1991	3503/3503A	PASSENGER
MAZDA	Protege	4-Cyl. 1.8 L	2000-1999	9337/9337A	PASSENGER
MAZDA	Protege	4-Cyl. 2.0 L	2003-2001	9337/9337A	PASSENGER
MAZDA	Protege	4-Cyl. 1.8 L	1994-1990	9357	PASSENGER
MAZDA	Protege	4-Cyl. 1.5 L	1995	9366	PASSENGER
MAZDA	Protege	4-Cyl. 1.8 L	1998-1995	9366	PASSENGER
MAZDA	RX8	R2-1.3L	2008-2004	9437	PASSENGER
MAZDA	Tribute	V-6 3.0 L	2003	6202/6202A	PASSENGER
MAZDA	Tribute	V-6 3.0 L	2002-2001	6202/6202A	PASSENGER
MAZDA	TRIBUTE	V6-3.0L	2006-2003	6206	PASSENGER
MAZDA	TRIBUTE	V6-3.0L	2008	6206	PASSENGER
MAZDA	TRIBUTE	V6-3.0L	2003-2001	9311	PASSENGER
MAZDA	Tribute	4-Cyl. 2.0 L	2004-2001	9321	PASSENGER
MAZDA	TRIBUTE	V6-3.0L	2006-2003	9630	PASSENGER
MAZDA	TRIBUTE	V6-3.0L	2008	9630	PASSENGER
MAZDA	Tribute	4-Cyl. 2.3 L	2008	9336/9336A	PASSENGER
MAZDA	Tribute	4-Cyl. 2.3 L	2006-2005	9336/9336A	PASSENGER
MAZDA	Tribute	4-Cyl. 2.3 L Electric Assist	2008	9336/9336A	PASSENGER
MAZDA	Tribute	4-Cyl. 2.5 L	2010-2009	9336/9336A	PASSENGER
MAZDA	Tribute	4-Cyl. 2.5 L Electric Assist	2011	9336/9336A	PASSENGER
MAZDA	Tribute	4-Cyl. 2.5 L Electric Assist	2010-2009	9336/9336A	PASSENGER
MAZDA	Tribute	V-6 3.0 L	2009	9336/9336A	PASSENGER
MAZDA	XEDOS 9 (TA)	V6-2.3L	95/02-00/01	9640	PASSENGER