

Make	Model	Engine	Year	DECOOL #	Purpose
Toyota Motor (import)	YARIS (_P1_) 1.0 (SCP10_)	1	2003-2005	9109	PASSENGER
Toyota Motor (import)	PRIUS Liftback (_W2_) 1.5 Hybrid (NHW20_)	1.5	2003-2009	9109	PASSENGER
Toyota Motor (import)	PRIUS Saloon (_W1_) 1.5 Hybrid (NHW1_)	1.5	2000-2004	9109	PASSENGER
Toyota Motor (import)	YARIS VERSO (_P2_) 1.4 D-4D (NLP20_, NLP22_)	1.4	2000-2005	9109	PASSENGER
TOYOTA	4 Runner	V-6 3.4 L	2002-1996	9340	PASSENGER
TOYOTA	4 Runner	4-Cyl. 2.4 L	1995-1985	9343	PASSENGER
TOYOTA	4 Runner	4-Cyl. 2.4 L	1984	9370	PASSENGER
TOYOTA	4 Runner	V-6 3.0 L	1989-1988	9394	PASSENGER
TOYOTA	4 Runner	V-6 3.0 L	1992-1990	9395	PASSENGER
TOYOTA	4 Runner	4-Cyl. 2.7 L	2010	9520	PASSENGER
TOYOTA	4 Runner	4-Cyl. 2.7 L	2000-1996	9520	PASSENGER
TOYOTA	AURIS (_E18_) 1.3 (NRE180_)	1.4L	2012-2018	1218	PASSENGER
TOYOTA	AURIS (NRE15_, ZZE15_, ADE15_, ZRE15_, NDE15_) 1.8 Hybrid	1.8L	06/10 -10/09	1209	PASSENGER
TOYOTA	AURIS TOURING SPORTS (ADE18_, ZWE18_, ZRE18_) 1.8 Hybrid	1.8L	13/07 - /	1209	PASSENGER
TOYOTA	Avalon	V-6 3.0 L	2004-1995	9318	PASSENGER
TOYOTA	AVALON	V6 3.5L	2005-2011	9576/9576U	PASSENGER
TOYOTA	Camry	4-Cyl. 2.0 L	1986-1983	9312	PASSENGER
TOYOTA	Camry	4-Cyl. 2.0 L	1991-1987	9313	PASSENGER
TOYOTA	Camry	4-Cyl. 2.2 L	2001-1992	9313	PASSENGER
TOYOTA	Camry	V-6 3.0 L	2006-1994	9318	PASSENGER
TOYOTA	Camry	V-6 3.3 L	2006-2004	9318	PASSENGER
TOYOTA	Camry	4-Cyl. 2.4 L	2009-2002	9354	PASSENGER
TOYOTA	Camry	4-Cyl. 2.4 L Electric Assist	2011-2007	9354	PASSENGER
TOYOTA	Camry	2.0	2006-2010	9374	PASSENGER
TOYOTA	Camry	2.4	2006-2010	9374	PASSENGER
TOYOTA	Camry	L4-2.5L	2012-2010	9405	PASSENGER
TOYOTA	Camry	V6 3.5L	2007-2011	9576/9576U	PASSENGER
TOYOTA	Camry	2		9670	PASSENGER
TOYOTA	Camry	2.0L	2015-2018	9670	PASSENGER
TOYOTA	Camry	2.0L	2017-	9670	PASSENGER
TOYOTA	Camry Solara	4-Cyl. 2.2 L	2000-1999	9313	PASSENGER
TOYOTA	Camry Solara	V-6 3.0 L	2000-1999	9318	PASSENGER
TOYOTA	Celica	4-Cyl. 2.0 L	1986	9312	PASSENGER
TOYOTA	Celica	4-Cyl. 2.0 L	1989-1988	9313	PASSENGER
TOYOTA	Celica	4-Cyl. 2.0 L	1987	9313	PASSENGER
TOYOTA	Celica	4-Cyl. 2.2 L	1999-1990	9313	PASSENGER
TOYOTA	Celica	4-Cyl. 2.4 L	1985	9343	PASSENGER
TOYOTA	Celica	4-Cyl. 1.6 L	1993-1990	9363	PASSENGER
TOYOTA	Celica	4-Cyl. 134	1979-1978	9370	PASSENGER
TOYOTA	Celica	4-Cyl. 2.2 L	1980	9370	PASSENGER
TOYOTA	Celica	4-Cyl. 2.4 L	1984-1981	9370	PASSENGER
TOYOTA	Celica	4-Cyl. 2.0 L	1993-1990	9529	PASSENGER
TOYOTA	Celica	4-Cyl. 2.0 L	1989-1988	9529	PASSENGER
TOYOTA	CELICA	L4-1.8L	2005-2000	9619	PASSENGER
TOYOTA	Celica	4-Cyl. 1.8 L	2005-2000	9336/9336A	PASSENGER

Make	Model	Engine	Year	DECOOL #	Purpose
TOYOTA	C-HR (_X1_) 1.8 Hybrid (ZYX10_ , ZYX11_)	1.8L	2016-	1217	PASSENGER
TOYOTA	Corolla	4-Cyl. 2.4 L	2010-2009	9354	PASSENGER
TOYOTA	Corolla	4-Cyl. 2.4 L	2012-2011	9354	PASSENGER
TOYOTA	Corolla	4-Cyl. 1.6 L	1997-1993	9361	PASSENGER
TOYOTA	Corolla	4-Cyl. 1.6 L	1992	9363	PASSENGER
TOYOTA	Corolla	4-Cyl. 1.6 L	1991-1990	9363	PASSENGER
TOYOTA	Corolla	4-Cyl. 1.6 L	1989	9363	PASSENGER
TOYOTA	Corolla	4-Cyl. 1.6 L	1988	9363	PASSENGER
TOYOTA	Corolla	4-Cyl. 1.6 L	1987	9363	PASSENGER
TOYOTA	Corolla	4-Cyl. 1.6 L	1986-1985	9363	PASSENGER
TOYOTA	Corolla	4-Cyl. 1.6 L	1984	9363	PASSENGER
TOYOTA	COROLLA	L4-1.8L	2009	9436	PASSENGER
TOYOTA	COROLLA	L4-1.8L	2006-2005	9619	PASSENGER
TOYOTA	Corolla	4-Cyl. 1.8 L	2008-2007	9336/9336A	PASSENGER
TOYOTA	Corolla	4-Cyl. 1.8 L	2006-2005	9336/9336A	PASSENGER
TOYOTA	Corolla	4-Cyl. 1.8 L	2004-1998	9336/9336A	PASSENGER
TOYOTA	COROLLA Estate (_E21_) 1.8 Hybrid (ZWE211)	1.8L	2019-	1217	PASSENGER
TOYOTA	COROLLA Hatchback (_E21_) 1.8 Hybrid (ZWE211)	1.8L	2018-	1217	PASSENGER
TOYOTA	COROLLA Saloon (_E18_ , ZRE1_) 1.3 (NRE180_)	1.4L	2013-2018	1218	PASSENGER
TOYOTA	COROLLA Saloon (_E21_) 1.8 VVTi Hybrid (ZWE211)	1.8L	2019-	1217	PASSENGER
TOYOTA	Corona	4-Cyl. 134	1979-1978	9370	PASSENGER
TOYOTA	Corona	4-Cyl. 2.2 L	1980	9370	PASSENGER
TOYOTA	Corona	4-Cyl. 2.4 L	1982-1981	9370	PASSENGER
TOYOTA	Echo	4-Cyl. 1.5 L	2005-2000	9509	PASSENGER
TOYOTA	HIACE III Box (H50)	2.4/2.0	198908 - 199508	9521	PASSENGER
TOYOTA	HIACE III Wagon (H50)	2.4/2.0	198908 - 199508	9521	PASSENGER
TOYOTA	Highlander	V-6 3.0 L	2003-2001	9318	PASSENGER
TOYOTA	Highlander	V-6 3.3 L	2007-2004	9318	PASSENGER
TOYOTA	Highlander	V-6 3.3 L	2008	9318	PASSENGER
TOYOTA	Highlander	V-6 3.3 L	2010-2006	9318	PASSENGER
TOYOTA	Highlander	4-Cyl. 2.4 L	2007-2001	9354	PASSENGER
TOYOTA	Highlander	L4-2.7L	2012-2009	9405	PASSENGER
TOYOTA	HIGHLANDER	V6 3.5L	2008-2011	9576/9576U	PASSENGER
TOYOTA	LAND CRUISER	V8-5.7L	2011-2008	9418	PASSENGER
TOYOTA	LAND CRUISER	V8-5.7L	2013	9418	PASSENGER
TOYOTA	LAND CRUISER	L6-4.5L	97-93	9464	PASSENGER
TOYOTA	Matrix	4-Cyl. 2.4 L	2013-2009	9354	PASSENGER
TOYOTA	MATRIX	L4-1.8L	2010-2009	9436	PASSENGER
TOYOTA	MATRIX	L4-1.8L	2006-2003	9619	PASSENGER
TOYOTA	Matrix	4-Cyl. 1.8 L	2008-2007	9336/9336A	PASSENGER
TOYOTA	Matrix	4-Cyl. 1.8 L	2006-2003	9336/9336A	PASSENGER
TOYOTA	MPV SIENNA	L4-2.7L	2012-2011	9405	PASSENGER
TOYOTA	MR2	4-Cyl. 2.2 L	1995-1991	9313	PASSENGER
TOYOTA	MR2	4-Cyl. 2.0 L	1995-1991	9529	PASSENGER
TOYOTA	MR2 Spyder	4-Cyl. 1.8 L	2005-2000	9336/9336A	PASSENGER

Make	Model	Engine	Year	DECOOL #	Purpose
TOYOTA	Paseo	4-Cyl. 1.5 L	1995-1992	9390	PASSENGER
TOYOTA	PASEO	L4-1.5L	1999-1996	9620	PASSENGER
TOYOTA	Pickup	4-Cyl. 2.4 L	1995-1985	9343	PASSENGER
TOYOTA	Pickup	4-Cyl. 134	1979	9370	PASSENGER
TOYOTA	Pickup	4-Cyl. 2.2 L	1980	9370	PASSENGER
TOYOTA	Pickup	4-Cyl. 2.4 L	1984-1981	9370	PASSENGER
TOYOTA	Pickup	V-6 3.0 L	1990	9394	PASSENGER
TOYOTA	Pickup	V-6 3.0 L	1989	9394	PASSENGER
TOYOTA	Pickup	V-6 3.0 L	1988	9394	PASSENGER
TOYOTA	Pickup	V-6 3.0 L	1992-1991	9395	PASSENGER
TOYOTA	Pickup	V-6 3.0 L	1990	9395	PASSENGER
TOYOTA	Pickup	V-6 3.0 L	1990	9395	PASSENGER
TOYOTA	Pickup	V-6 3.0 L	1989	9395	PASSENGER
TOYOTA	prado 4000			9621	PASSENGER
TOYOTA	PREVIA	ACR50	2006-2010	9374	PASSENGER
TOYOTA	Prius	4-Cyl. 1.5 L Electric Assist	2009-2001	9509	PASSENGER
TOYOTA	PRIUS (_W5_) 1.8 Hybrid (ZVW50_ , ZVW51_)	1.8L	2015-	1217	PASSENGER
TOYOTA	PRIUS (_W5_) 1.8 Hybrid E-Four 4WD (ZVW55_)	1.8L	2015-	1217	PASSENGER
TOYOTA	PRIUS (ZVW3_) 1.8 Hybrid	1.8L	09/04 - /	1209	PASSENGER
TOYOTA	PRIUS PHV (_W52_) 1.8 Plug-in Hybrid (ZVW52)	1.8L	2016-	1217	PASSENGER
TOYOTA	PRIUS PLUS (ZVW4_) 1.8 Hybrid	1.8L	2011/05 - /	1209	PASSENGER
TOYOTA	RAV4	4-Cyl. 2.0 L	2000-1996	9313	PASSENGER
TOYOTA	RAV4	4-Cyl. 2.0 L	2003-2001	9354	PASSENGER
TOYOTA	RAV4	4-Cyl. 2.4 L	2008-2004	9354	PASSENGER
TOYOTA	RAV4	2.0	2006-2010	9374	PASSENGER
TOYOTA	RAV4	2.4	2006-2010	9374	PASSENGER
TOYOTA	RAV4	L4-2.5L	2011-2009	9405	PASSENGER
TOYOTA	RAV4	V6 3.5L	2006-2011	9576/9576U	PASSENGER
TOYOTA	SEQUOIA	V8-5.7L	2012-2008	9418	PASSENGER
TOYOTA	Sienna	V-6 3.0 L	2003-1998	9318	PASSENGER
TOYOTA	Sienna	V-6 3.3 L	2006-2004	9318	PASSENGER
TOYOTA	SIENNA	V6 3.5L	2007-2011	9576/9576U	PASSENGER
TOYOTA	Solara	4-Cyl. 2.2 L	2001	9313	PASSENGER
TOYOTA	Solara	V-6 3.0 L	2003-2001	9318	PASSENGER
TOYOTA	Solara	V-6 3.3 L	2008-2004	9318	PASSENGER
TOYOTA	Solara	4-Cyl. 2.4 L	2008-2002	9354	PASSENGER
TOYOTA	T100	V-6 3.4 L	1998-1995	9340	PASSENGER
TOYOTA	T100	V-6 3.4 L	1998-1995	9345	PASSENGER
TOYOTA	T100	4-Cyl. 2.7 L	1998-1995	9520	PASSENGER
TOYOTA	Tacoma	V-6 3.4 L	2004-2002	9340	PASSENGER
TOYOTA	Tacoma	V-6 3.4 L	2001-1995	9340	PASSENGER
TOYOTA	Tacoma	V-6 3.4 L	2001-1995	9345	PASSENGER
TOYOTA	Tacoma	4-Cyl. 2.4 L	2004-1995	9520	PASSENGER
TOYOTA	Tacoma	4-Cyl. 2.7 L	2013-2001	9520	PASSENGER
TOYOTA	Tacoma	4-Cyl. 2.7 L	2000	9520	PASSENGER

Make	Model	Engine	Year	DECOOL #	Purpose
TOYOTA	Tacoma	4-Cyl. 2.7 L	1999-1995	9520	PASSENGER
TOYOTA	Tercel	4-Cyl. 1.5 L	1994	9390	PASSENGER
TOYOTA	Tercel	4-Cyl. 1.5 L	1993-1989	9390	PASSENGER
TOYOTA	Tercel	4-Cyl. 1.5 L	1988-1987	9390	PASSENGER
TOYOTA	TERCEL	L4-1.5L	1999-1995	9620	PASSENGER
TOYOTA	Tundra	V-6 3.4 L	2004-2000	9340	PASSENGER
TOYOTA	Tundra	V-6 3.4 L	2004-2000	9345	PASSENGER
TOYOTA	TUNDRA	V8-5.7L	2012-2007	9418	PASSENGER
TOYOTA	Van	4-Cyl. 2.0 L	1985-1984	9504	PASSENGER
TOYOTA	Van	4-Cyl. 2.2 L	1989-1986	9504	PASSENGER
TOYOTA	VENZA	L4-2.7L	2013-2009	9405	PASSENGER
TOYOTA	VENZA	V6 3.5L	2009-2010	9576/9576U	PASSENGER
TOYOTA	VIOS (_P15_) 1.3 (NSP150)	1.3L	2013-	9117	PASSENGER
TOYOTA	VIOS FS Hatchback (_P15_) VVTi (NSP151)	1.5L	2019-	9117	PASSENGER
TOYOTA	VITZ (_P1_)	1.0 16V	199904 - /	9540	PASSENGER
TOYOTA	Wish	2.0L	2009-	9681	PASSENGER
TOYOTA	Yaris	4-Cyl. 1.5 L	2013-2007	9509	PASSENGER
TOYOTA	Yaris	4-Cyl. 1.5 L	2006	9509	PASSENGER
Toyota Motor (import)	YARIS (_P1_) 1.5 (NCP13_)	1.5	2001-2005	9109	PASSENGER
TOYOTA	YARIS (_P13_) 1.3 (NSP130_)	1.4L	2010-	1218	PASSENGER
TOYOTA	YARIS (_P13_) 1.3 (NSP130_)	1.4L	2011-	1218	PASSENGER
TOYOTA	YARIS (_P13_) 1.3 4WD (NSP135_)	1.4L	2010-	1218	PASSENGER
TOYOTA	YARIS L Hatchback (_P15_) 1.5 (NSP151)	1.5L	2018-	9117	PASSENGER
Toyota Motor (import)	YARIS VERSO (_P2_) 1.3 (NCP20_, NCP22_)	1.3	2002-2005	9109	PASSENGER
Toyota Motor (import)	YARIS VERSO (_P2_) 1.5 (NCP21_)	1.5	2000-2005	9109	PASSENGER
TOYOTA	YARIS/VITZ (NHP13_, NSP13_, NCP13_, KSP13_, NLP13_) 1.5 Hybrid	1.8L	10/12 -12/03	1209	PASSENGER
TOYOTA	YARIS/VITZ (SCP1_, NLP1_, NCP1_)	4-1.0	1999-2005	9623	PASSENGER
TOYOTA	YARIS/VITZ (SCP1_, NLP1_, NCP1_)	4-1.0	1999-2005	9624	PASSENGER